

Parametri za setovanje skenera Metrologic MS-9520 i MS-7220Argus

Enter/Exit Configuration Mode



Recall Defaults



Enable RS-232.



Enable STX Prefix.



Enable UPC Prefix ID.



Transmit Lead Zero on UPC-E.



Odd Parity.



4800 BAUD Rate.



Enable RTS/CTS Handshaking.



Enter/Exit Configuration Mode

