

Chart 1) The detail contents of online status.

ERROR code		The contents of ERROR's type	The contents of ERROR's DETAIL
Types of ERROR	Detail of ERROR		
00	00	Normal END	
01	01	Data check ERROR	Command Field ERROR ->The command data of the parameter packet was incorrect.
01	04		Received FDS packet size ERROR. ->The size of received FDS packet was incorrect.
01	05		Received data packet size ERROR. ->The size of received data packet was incorrect.
01	06		Unknown text data was received. ->The received data contained characters other than "0"- "9", "A"- "F".
01	07		File type ERROR ->Received data on Departments or PLUs with information about their types was different from the one in POS.
01	10		Undefined file (or RAM table No.) was received. ->The file No. or RAM table No. in the received FDS packet was wrong.
02	00		RS232 transmission ERROR
02	01	Line has been disconnected.	
02	02	ER off error. ->The power-off is occurred.	
02	03	DR off error. ->The DR signal is turned off.	

ERROR code		The contents of ERROR's type	The contents of ERROR's DETAIL
Types of ERROR	Detail of ERROR		
02	04	RS232 transmission ERROR	CD off error at receiving sequence. -> The CD signal is turned off.
02	05		CD on error at transmission sequence -> The CD signal is turned on.
02	06		CS off error at transmission sequence -> The CS signal is turned off.
02	07		Time out error at receiving data. Retry over error at transmission data.
02	08		PRINTER BUSY error Retry over at printer busy
03	00	RS232 transmission protocol ERROR	The following error occurs. 1) When receiving parameter text, EOT was received. 2) In the processing on up-loading, data other than EOT was received. 3) EOT was received after NAK was sent.
04	01	File access ERROR	Command error
04	02		Specified file did not exist.
04	03		Specified block did not exist.
04	04		Specified record did not exist.
04	05		File full
04	06		File type error
04	07		Area over
04	08		Illegal mixture of Block-and non Block-tables
04	11	File creation/delete ERROR	

ERROR code		The contents of ERROR's type	The contents of ERROR's DETAIL
Types of ERROR	Detail of ERROR		
06	00	Parameter ERROR	The format of parameter packet was wrong.
06	01		The contents of parameter 1 was wrong.
06	02		The contents of parameter 2 was wrong.
06	03		The contents of parameter 3 was wrong.
06	04		The contents of parameter 4 was wrong.
06	05		The contents of parameter 5 was wrong.
06	11		Specified job did not exist (X/Z)
06	13		Range specification error (X/Z) -> Programming of range specification (Start code, End code), Group No. etc. were not adequate.
06	22		Specified file did not exist (DL) -> When a certain job was performed, the file which was necessary for it was not created in ECR.
06	23		Range specification error (DL) -> Programming of range specification (Start code, End code) were not adequate.
08	00		(Reserve) <1
09	00	RJE ERROR	RJE JOB is not executed yet in ECR when status inquire job is received.
09	01		"RJE file was set by RJE file create/delete JOB" or "RJE command is received when last RJE JOB is not executed yet in ECR".